

# Kuormitustaulukko

		<b>B10</b>	<b>B16</b>	<b>B20</b>	<b>C10</b>	<b>C16</b>	<b>C20</b>
MDL401	ON/OFF	13	22	27	22	37	45
MDL401	DALI	11	18	22	18	30	37
MDL801	ON/OFF	11	22	27	22	37	45
MDL801	DALI	11	18	22	18	30	37
MDL1201	ON/OFF	7	12	15	12	20	24
MDL1201	DALI	7	12	15	12	20	24
MDL1601	ON/OFF	6	10	12	10	17	21
MDL1601	DALI	6	10	12	10	17	21

# Kuormitustaulukko

		<b>B10</b>	<b>B16</b>	<b>B20</b>	<b>C10</b>	<b>C16</b>	<b>C20</b>
PRL401	ON/OFF	13	22	27	22	37	45
PRL401	DALI	11	18	22	18	30	37
PRL601	ON/OFF	13	22	27	22	37	45
PRL601	DALI	11	18	22	18	30	37
PRL801	ON/OFF	13	22	27	22	37	45
PRL801	DALI	11	18	22	18	30	37
PRL1001	ON/OFF	13	22	27	22	37	45
PRL1001	DALI	11	18	22	18	30	37
PRL1201	ON/OFF	7	12	15	12	20	24
PRL1201	DALI	7	12	15	12	20	24
PRL1401	ON/OFF	7	12	15	12	20	24
PRL1401	DALI	7	12	15	12	20	24
PRL1601	ON/OFF	6	10	12	10	17	21
PRL1601	DALI	6	10	12	10	17	21